

Assembly instruction

Streamline Seats

Model „Vento short“
(Lambretta Series 2 und 3)
Standard Fastening-system



CONTENTS

- 1 x upholstered seat with mounted lock
- 2 x keys
- 2 x allen screw M8x50
- 2 x allen screw M8x40
- 2 x nut M8, standard
- 2 x nut M8, flat design
- 4 x self-locking nut M8
- 12 x washer M8
- 2 x oval frame bracket
- 1 x locking bracket frame



Installation

Step 1:

Front side frame: Screw in the two flat M8 nuts completely on the M8x40 allen screws. Support the oval frame bracket with one or two M8 washers on the left and right side and fasten it to the frame with the M8x40 allen screws and the M8 self-locking nuts.



Step 2:

Rear side frame:

Screw in the two standard M8 nuts completely on the M8x50 allen screws.

Support the oval frame bracket with one M8 washer on the left and right side and fasten it to the frame with the M8x40 allen screws, the locking bracket and the M8 self-locking nuts. Position of the locking bracket: see left picture



Fully assembled fastening-system.



Step 3:

Completely screw in all rubber buffers on the inside of the seat and slide it on the fastening system that is attached to the frame.

If this is not possible, adjust the height of the corresponding allen screws accordingly.

Lift the seat up at the front and back side of the frame and minimize the vertical play by adjusting the height of the corresponding rubber buffers.



Step 4:

Screw out the two rubber buffers on the side of the seat until they make contact with the frame.

Once the seat is completely adjusted, lock the height of all rubber buffers by tightening the counter nuts under the buffers.

Subsequently test if the seat can still be slid on the fastening system and the vertical play is reduced to a minimum.



Step 5:

Use a torch to illuminate the inside locking system.

Check if the locking bracket that is attached to the lock sits in front of the locking bracket that is attached to the frame when the key is turned. If necessary, adjust the locking bracket of the frame by moving it a bit back or forward.



Step 6:

Removal of the seat: Unlock the seat and push it forward by simultaneously applying a slight pressure to the rear side of the seat.

No warranty is given on damages or subsequent damages that were caused by an improper installation.
Due to legal reasons for decoration purposes only.