

Assembly Instructions

Streamline Seats

Model "Pulse Touring"
(Vespa Smallframe)



Scope of supply

- 1 x upholstered seat with front hinge
- 1 x Frame plate for magnet
- 3 x M7x20 hexagon bolt
- 1 x Hex nut M7
- 6 x Washer for M7



Installation

Step 1: Unscrew the two bolts for the mounting of the old seat and remove the seat.



Step 2: Pad the hinge with 2 x M7 washers over the threaded holes on the frame to compensate for the height of the frame flange. Then fasten the hinge to the frame using 2 x M7x20 hex bolts and 2 x M7 washers.



Step 3: Remove the cone bolt for the locking mechanism of the old seat..



Step 4: Fasten the frame plate for the magnet with an M7x20 hex bolt and an M7 washer. If the M7 thread on the frame is no longer present, the supplied M7 nut and washer can be used to secure the bolt. If necessary, adjust the horizontal position of the seat using the elongated holes on the hinge.