

Assembly Instruction
Streamline Seats
Model "Pace"
Model "Viper"
(Vespa Largeframe Oldie)



CONTENTS

- 1 x upholstered seat with mounted lock
- 2 x keys
- 4 x hexagon bolt M7x40
- 1 x hexagon bolt M7x20
- 4 x nut M7
- 5 x washer M7
- 1 x locking bracket



INSTALLATION

Step 1:

Unscrew the front bolts for the mounting of the old seat as well as for the tank and remove the seat.

Step 2:

Unscrew the two rear bolts for the mounting of the tank.



Step 3:

Remove the cone bolt for the locking mechanism of the old seat.

**Step 4:**

Place the seat on the frame and evenly adjust the height of the four rubber buffers in the middle and rear so the seat does not touch the frame

Lock the height of the buffers by fastening the counter-nuts.

Important: The height of the two front rubber buffers will be adjusted in Step 7.

**Step 5:**

Screw in the four M7x40 hexagon bolts for the fixing of the tank together with the M7 washers and nuts.

Tighten the counter-nuts slightly.

**Step 6:**

Put the seat on the bolts and push it backward.

Next, pull up the seat in the front and back to determine the vertical clearance. Reduce the clearance to a minimum by adjusting the height of the bolts accordingly. Tighten the counter-nuts afterwards. If the seat can't be put on, simply increase the height of the bolts.

Tip: Measure the final height of the bolts and write down the values in case the tank has to be removed in the future

**Step 7:**

Adjustment of the front rubber buffers:

Put the seat on the bolts and push it backward into the final position.

Vertically push on the front to determine the clearance of the front tip. Reduce the clearance by adjusting the height of the front rubber buffer.

**Step 8:**

Mount the locking bracket to the front of the frame together with the M7x20 hexagon bolt and the M7 washer. Pull the bracket completely backwards and tighten the bolt.



Step 9:

Position the seat on the mounting system and move it backward into the final position. Turn and remove the key.

If too much horizontal clearance of the seat is detectable, unscrew the locking bracket and re-position it a little bit backwards

Removal: Unlock the seat and move it forward by slightly pushing against the back.

No warranty is given on damages or subsequent damages that were caused by an improper installation.
Due to legal reasons for decoration purposes only.